

# SIP Phone



VM-9200-SMLT(S) / VM-9100-SMLT(S)

**QIG**  
**V 1.00**

---

# 1 Overview

This phone is a full-feature telephone that provides voice communication. Read this QIG carefully to learn how to operate this product and take advantage of its features.

## Package Contents


When unpacking the phone, ensure all the following items are present and undamaged. If anything appears to be missing or broken, contact your dealer for a replacement.

1. Base Unit
2. Handset
3. Stand
4. AC Adaptor
5. RJ-45 Cable
6. Quick Installation Guide (This document)

## 2 Product Description

The following contains important information to help you familiarize with the functions of the VoIP phone.


### Front View



## 1. Base unit keys

|   | Name                    | Description   |
|---|-------------------------|---|
| 1 | Display screen          | To display calls and status information.  |
| 2 | Alphanumerical keys     | Press these keys to enter phone numbers and texts.  |
| 3 | Function keys           |   |
|   | LANGUAGE                | Press to select display language  |
|   | EMERGENCY               | Press to make an emergency call.  |
|   | HOME                    | Press to return to idle page  |
|   | LINE 1 / LINE 2         | To indicate a line been used as the following status:<br>- Idle: No LED indication.<br>- Call on hold: Red LED flash<br>- In call: Red LED. |
|   | HOLD (2 line only)      | Press to put an active call on hold.  |
|   | MUTE (single line only) | Press to mute MIC.  |
|   | REDIAL                  | Press to call the last dialed number.   |
|   | SPEAKER                 | Press to activate the speakerphone for hands free conversations.  |
|   | VOLUME UP/DOWN          | Press to increase or decrease the volume of the ringer tone or speakerphone.  |

## Back View




| NO. | Name             | Description  |
|-----|------------------|--|
| 1   | LAN port         | Connects to HUB, ADSL, or Switch(PSE)  |
| 2   | PC port          | Connects to computer   |
| 3   | DC 5V Power jack | Connects to AC power adapter. (Optional. While base unit is not powered via a PSE) |
| 4   | Handset jack     | Connects to handset.   |

## Connecting the Phone

The following illustration shows how to connect the power, LAN and PC ports of VoIP phone.



The following illustration shows how to install the phone and stand.



## 3 Operation

### Answering a Call

An incoming call is indicated by a ringing tone. You can answer the call by doing one of the followings:

- Pick up the **Handset** to answer the call.
- Press the **LINE (LINE1/LINE2)** key to answer the call.

### Making a Call

#### Dialing with the Keypad

- Enter the telephone number with the alphanumerical keypad.
- After entering the number you want to call, press the # key to force dialing or wait for 4 seconds before the number is dialed automatically.


### Using the Programmable Service keys

You can use the pre-assigned service hotkeys, to configure the most commonly dialed numbers. Use the function to dial a number quickly, instead of keying in a complete number.

To call a number using service hotkeys, follow the steps below:

- Press the service hotkeys that has been pre-assigned to the phone number and the call will start automatically.

## Using the on-screen programmable service function soft keys



You can use the pre-assigned service function, to configure the most commonly dialed numbers. Use the function to dial a number quickly, instead of keying in a complete number.

To call a number using service soft keys dialing, follow the steps below:

- Press **hotel Services** soft key.
- Press service icon soft key to precede service dial.

## Call Options

While a call is in progress, a number of additional options are available.

## Using the Speaker Phone

For hands free operation, you can use the built-in speaker to talk on the phone. To use the speakerphone, follow the steps below:

- While talking on the phone, press the **SPEAKER** key on the phone to enable the Speakerphone function.
- Press **SPEAKER** key again to terminate the call.

## Putting a Call on Hold

You may want to put a call on hold temporarily while doing some work or attending to a second incoming or outgoing call. To put a call on hold, do one of the following:

- Press the **HOLD** key on the phone to put the call on hold.
- When you receive a second call, press the next available **LINE** key to attend to the new call, and the first call will be put on hold automatically.

## Checking Voice Messages

If the **MESSAGE** key LED in red, it indicates that there are one or more new messages in voicemail box.

- Press the **MESSAGE** key on the phone to retrieve voice messages.

(An external ITSP or PBX must support voice message feature. And you need to set a voice message code before using the voice mail feature.)

## Pairing handset and base unit

Manual pairing:

- On the base, press \*112\*810# to start pairing mode(broadcast RFPI)
- Press \*\*6862\* and select "Subscribe" on a handset. A sequence of RFPI number shows in handset display if a nearby base is in pairing mode.
- If shown RFPI matches the numbers printed at the back of the base, press **LINE (LINE 1)** key to confirm pairing.
- Otherwise, press # key to search again.

To pair multiple handsets to a base: (The base must be configured to pair with multiple handsets)

- Reset base pairing by pressing \*112\*811# on the base
- Pair handsets one by one via automatic or manual pairing described above

## 4 Support

To configure through the web browser, do the following:

- Ensure the phone is powered up and connected to a DCHP network.
- Press HOLD/MUTE \*112\*113# (HOLD for 2-Line / MUTE for 1-Line), the IP address is displayed on the LCD screen.
- Open your browser (such as Internet Explorer, Firefox, etc.) and type in the web address of the phone. For example, if the IP address you obtain in step 4 above is 192.168.1.2, enter the web address: http:// 192.168.1.2:8000.
- When the Web login front page is displayed. Enter the user name and the password and click **Login**.  
The administrator's user name and password are "**admin**" and "**1234**" respectively.

For technological support, please email to [support@aeicommunication.com](mailto:support@aeicommunication.com).

---