

Analog Phone

AVM-6108-S/AVM-6104-S

QIG v1.0



1 Over view

This phone is a full-feature telephone that provides voice communication. Read this QIG carefully to learn how to operate this product and take advantage of its features.

Package Contents

When unpacking the Analog phone, ensure all the following items are present and undamaged. If anything appears to be missing or broken, contact your dealer for a replacement.

1. Base Unit
2. Handset
3. Coiled Handset Cord
4. Line Cord
5. Clear Plastic Faceplate
6. User Guide

2 Product Description

This chapter contains important information to help you familiarize yourself with the functions of the Analog phone.

Front View

VM-6108-S DIAGRAM (FRONT)




Name	Description
1 Speed dial keys	Press to dial one touch of guest services or PBX features. Programmed during installation.
2 Dialing Pad	Press the buttons to dial a phone number or enter alphabetical characters.
3 Speed dial keys	Press to dial one touch of guest services or PBX features. Programmed during installation.
4 VOLUME	Press to increase or decrease the volume.

	Name	Description
5	REDIAL	Press to automatically redial the last number dialed
6	MUTE	Press to mute MIC.
7	SPEAKER	Press to hear using speaker.

3. Installation

The following illustration shows how to install the phone and stand.



4 Operation

Answering a Call

An incoming call is indicated by a ringing tone and a flashing indicator at the top of base. You can answer the call by doing one of the followings:

USING THE HANDSET

- Pick up the **handset** to answer the call.

USING THE SPEAKER PHONE

- Press the **Speaker** key.

Making a Call

USING THE HANDSET

- Pick up the **handset**, dial telephone number with the alphanumerical keypad.

USING THE SPEAKER PHONE

- Press the **Speaker** key, dial telephone number with the alphanumerical keypad.

For technical support, please email to support@aeicommunications.com.tw