

Analog Phone



RW-5102(A)

QIG

V 1.00

1 Over view

This phone is a full-feature telephone that provides voice communication. Read this QIG carefully to learn how to operate this product and take advantage of its features.

Package Contents

When unpacking the Analog phone, ensure all the following items are present and undamaged. If anything appears to be missing or broken, contact your dealer for a replacement.

1. **Base Unit**
2. **Handset with coil cord**
3. **Line Cord**
4. **Quick Installation Guide (This document)**

2 Product Description

This chapter contains important information to help you familiarize yourself with the functions of the analog phone.


Front View



	Name	Description
1	Dialing Pad	Press the buttons to dial a phone number or enter alphabetical characters.
2	Speed dial Service Keys	Press any of the keys to speed dial the preset number.
3	Receiver control switch	Switch HIGH or NORMAL for receiver volume
4	Ringer control switch	Switch HIGH or LOW for ring volume

3. Installation

The following illustration shows how to install the phone on the wall.



4. Operation

Answering a Call

An incoming call is indicated by a ringing tone of base units. You can answer the call by doing one of the followings:

- Pick up the **Handset** to answer the call.

Making a Call

Dialing with the Keypad

- Enter the telephone number with the alphanumerical keypad.
- After entering the number you want to call, press the # key to force dialing or wait for 4 seconds before the number is dialed automatically.

Using the Speed dial keys

You can use the 2 pre-assigned speed dial hotkeys, to configure the most commonly dialed numbers. Use the function to dial a number quickly, instead of keying in a complete number.

To call a number using speed dialing, follow the steps below:

- Press the speed dial hotkey that has been pre-assigned to the phone number and the call will start automatically.

For technological support, please email to support@aeicommunication.com.