

# VoIP Phone

SLN-1100

QIG v1.0



# 1 Over view

This phone is a full-feature telephone that provides voice communication. Read this QIG carefully to learn how to operate this product and take advantage of its features

## Package Contents

When unpacking the VoIP phone, ensure all the following items are present and undamaged. If anything appears to be missing or broken, contact your dealer for a replacement.

1. Base Unit
2. Handset
3. Wall mount
4. AC Adaptor (Optional)
5. RJ-45 Cable
6. Quick Installation Guide (This document)

## 2 Product Description

This Chapter contains important information to help you familiarize yourself with the functions of the VoIP phone.


### Front View



	Name	Description
1	Ring Indicator	A red light indicator means that you have incoming calls.

## 3 Installation

The following illustration shows how to install the phone and stand.



## 4 Operation

### Answering a Call

An incoming call is indicated by a ringing tone and a flashing indicator at the top of handset and base units. You can answer the call by doing one of the followings:

- Pick up the **handset** to answer the call.

## 5 Support

To configure through the web browser, do the following:

- Ensure the phone is powered up and connected to a DCHP network.
- Pick up the handset and then press \*112\*113#, the IP address is announced by th phone.
- Open your browser (such as Chrome, Firefox, etc.) and type in the web address of the phone. For example, `http:// IP.address.of.thePhone:8000`
- When the Web login front page is displayed. Enter the use name and the password and click **Login**. The administrator's user name and password are "**admin**" and "**1234**" respectively.

For technical support, please email to [support@aeicomunications.com.tw](mailto:support@aeicomunications.com.tw)