

Analog DECT Phone



VM-8208-SMK(A) / VM-8108-SMK(A)

QIG
V 1.00

1 Overview

This phone is a full-feature telephone that provides voice communication. Read this QIG carefully to learn how to operate this product and take advantage of its features.

Package Contents


When unpacking the phone, ensure all the following items are present and undamaged. If anything appears to be missing or broken, contact your dealer for a replacement.

1. Base Unit
2. Handset
3. Stand
4. AC Adaptor
5. RJ-45 Cable
6. Quick Installation Guide (This document)

2 Product Description

The following contains important information to help you familiarize with the functions of the VoIP phone.

Front View




1. Base unit keys

	Name	Description
1	Programmable Services keys	Press to call preset service
2	Alphanumerical keys	Press these keys to enter phone numbers and texts.
3	Function keys	
	LINE 1 / LINE 2	To indicate a line been used as the following status: - Idle: No LED indication. - Call on hold: Red LED flash - In call: Red LED.
	HOLD (2 lines only)	Press to put an active call on hold.


Name	Description
MUTE (single line only)	Press to mute MIC.
REDIAL	Press to call the last dialed number.
SPEAKER	Press to activate the speakerphone for hands free conversations.
VOLUME UP/DOWN	Press to increase or decrease the volume of the ringer tone or speakerphone.
MESSAGE	Press to retrieve voice messages.

2 Handset keys



item	Name	Description
1	Display screen	Displays calls and status information.
2	SELECT SERVICES key	Press enter service function
3	Right / Left key	Press to choose service function.
4	LINE 1 / LINE 2	There are two LINEs bottom in this handset.
5	END key	Press to end the phone call
6	Alphanumerical keys	Press these keys to enter phone numbers and texts.
	Function keys	
	HOLD (2 line only)	Press to put an active call on hold.
	MUTE (single line only)	Press to mute MIC.
	SPEAKER	Activates the speakerphone to allow hands free conversations.
	VOLUME	Press to increase or decrease the volume of the ringer tone, handset, or the volume of the current call using the speakerphone. There are three levels: small, middle and large volume.
	MESSAGE	Press to listen to voice messages.
	FRONT DESK	Press to contact with front desk service.
	EMERGENCY	Press to make an emergency call.


Back View




NO.	Name	Description
1	DC Power jack	Connects to AC power adapter.
2	PSTN line port	Connects to PSTN line.

Connecting the Phone

The following illustration shows how to connect the power.



The following illustration shows how to install the phone and stand.



3 Operation

Answering a Call

An incoming call is indicated by a ringing tone and a flashing indicator at the top of units. You can answer the call by doing one of the followings:

- Pick up the **Handset** to answer the call.
- Press the **LINE (LINE1/LINE2)** key on the base or handset to answer the call.

Making a Call

Dialing with the Keypad

- Enter the telephone number with the alphanumerical keypad.
- After entering the number you want to call, press the # key to force dialing or wait for 4 seconds before the number is dialed automatically.

Using the Programmable Services keys

You can use the pre-assigned service hotkeys, to configure the most commonly dialed numbers. Use the function to dial a number quickly, instead of keying in a complete number.

To call a number using services hotkeys, follow the steps below:

- Press the service hotkeys that has been pre-assigned to the phone number and the call will start automatically.

Call Options

While a call is in progress, a number of additional options are available.

Using the Speaker Phone

For hands free operation, you can use the built-in speaker to talk on the phone. To use the speakerphone, follow the steps below:

- While talking on the phone, press the **SPEAKER** key on the phone to enable the Speakerphone function.
- Press **SPEAKER** key again to terminate the call.

Putting a Call on Hold

You may want to put a call on hold temporarily while doing some work or attending to a second incoming or outgoing call. To put a call on hold, do one of the following:

- Press the **HOLD** key on the phone to put the call on hold.
- When you receive a second call, press the next available **LINE** key to attend to the new call, and the first call will be put on hold automatically.

Checking Voice Messages

If the **MESSAGE** key in red, it indicates that there are one or more new messages in voicemail box.

- Press the **MESSAGE** key on the phone to retrieve voice messages.

4 Support

For technological support, please email to support@aeicommunication.com.
