

# VoIP Phone

**SFT-1100**

QIG v1.0



# 1 Over view

This phone is a full-feature telephone that provides voice communication. Read this QIG carefully to learn how to operate this product and take advantage of its features

## Package Contents

When unpacking the VoIP phone, ensure all the following items are present and undamaged. If anything appears to be missing or broken, contact your dealer for a replacement.

1. VoIP Phone
2. Handset
3. AC Adaptor (Optional)
4. RJ-45 Cable
5. Quick Installation Guide (This document)

## 2 Product Description

This Chapter contains important information to help you familiarize yourself with the functions of the VoIP phone.


### Front View



Name	Description
1 Ring Indicator	A red light indicator incoming calls or unheard messages

## 3 Installation

The following illustration shows how to install the phone on the wall.



## 4 Operation

### Answering a Call

An incoming call is indicated by a ringing tone and a flashing indicator at the top of handset. You can answer the call by doing one of the followings:

- Pick up the **handset** to answer the call.

## 5 Support

To configure through the web browser, do the following:

- Ensure the phone is powered up and connected to a DCHP network.
- Pick up the handset and then press \*112\*113#, the IP address is announced by th phone.
- Open your browser (such as Chrome, Firefox, etc.) and type in the web address of the phone. For example, <http://IP.address.of.thePhone:8000>
- When the Web login front page is displayed. Enter the use name and the password and click **Login**.  
The administrator's user name and password are "**admin**" and "**1234**" respectively.

For technical support, please email to [support@aeicomunications.com.tw](mailto:support@aeicomunications.com.tw)